

ENGLISH



**20" (51cm), 26" (66cm) INDUSTRIAL WALL FAN  
TYPHOON SERIES**



To get the best results from your Binatone product  
please read these instructions carefully.

**IWF-2021, IWF2600**

**Binatone has an incredible heritage.**

**Established – 1958 in London, UK.**

We are an absolutely customer centric company!

With more than 60 years delivering quality products to our customers in more than 75 countries – our global footprint enables economies of scale.

This allows us to offer you some of the world's highest performance, quality & value products available in the market today.

Our commitment lies solely in delivering high quality, affordable products.

Our international team is constantly pursuing every effort to make products not just 'appliances' but 'lifestyle improvements'.

Check out all the latest Binatone products at:

[www.binatonelifestyle.com](http://www.binatonelifestyle.com)



# IMPORTANT SAFEGUARDS

When using electrical appliances – especially when children are present, basic safety precautions should always be followed to reduce the risk of fire, electric shock and/or injury to persons.


- ✓ READ ALL INSTRUCTIONS
- ✓ Make sure your power supply is consistent with the rated specification of the product before connecting.
- ✓ This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge – unless they are under supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- ✓ Do not operate any electrical appliance with a damaged cord or plug – or after the appliance malfunctions or has been dropped or damaged in any manner. Return the appliance to the nearest authorised service facility for examination, repair or adjustment.
- ✓ This product is intended for domestic indoor use only. Do not use outdoors or for commercial purposes.
- ✓ To protect against electric shock, do not place the product, cord or plug in water or other liquid.
- ✓ This product should not be used in the immediate vicinity of water, such as bathtub, washbowls, swimming pool etc. where the likelihood of immersion or splashing could occur.
- ✓ Unplug from the power outlet when not in use & before cleaning.
- ✓ Do not pull, twist or otherwise abuse the power cord.
- ✓ Use this appliance only for its intended use – as described in this manual.
- ✓ Do not insert fingers, pencil or other articles through the slots during operation.
- ✓ The use of accessory attachments not included, recommended or sold by Binatone is prohibited and may cause damage, fire, electric shock or injury.
- ✓ Do not operate the fan in the presence of explosive and/or flammable fumes.
- ✓ Do not place the fan or any parts near an open flame, cooking or other heating appliance.
- ✓ Do not operate if the fan housing is removed or damaged.
- ✓ Do not operate the fan without the protective front and rear grilles in position.
- ✓ This product is made of high - quality materials, with auto resettable thermal cut-out/internal heat protector (single phase), three position speed selector.

**WARNING. To Reduce the Risk of Fire or Electric Shock  
Do Not Use This Fan with Any Solid-State Speed Control Device**

# SPECIFICATION

IWF-2021 Power : AC 230V~ 50Hz 130W  
 IWF-2600 Power: AC 230V~ 50Hz 190W

# KNOW YOUR APPLIANCE




# BEFORE FIRST USE

Carefully remove all packaging and assemble the product following the setup & operating instructions below.

# SETUP INSTRUCTIONS

1. Install the wall mount base on a strong wall (see Figure 1)
2. Install the bend tube into the wall mount base. Secure with the split pin (see Figure 2)
3. Install the fan head onto the female supporter end of the bend tube (see Figure 3)



**CAUTION :** Do not install the fan head onto the female supporter end of the bend tube BEFORE installing the bend tube to the wall mount base.

## SETUP INSTRUCTIONS continued

4. Remove the 4 screws from the motor unit front and fit the rear guard.
5. Refit the screws and tighten
6. Install the fan blade onto the shaft (ensure the holding screw is locked tight to the shaft)
7. Install the front guard
8. Install the speed switch box to the wall mount base. Secure it using the screw

## OPERATING INSTRUCTIONS

1. Make sure that the fan is on a firm and level surface.
2. Insert the plug into a standard AC 230V outlet.
3. The speed of the fan can be selected by using the pull cord.
  - 0 - to turn "off" the fan.
  - 1 - for low gentle, quiet operation.
  - 2 - for medium normal use.
  - 3 - for high quick cooling and maximum desired air movement.
4. Fan head can be oscillated from left to right.  
To operate – loosen the regulation screw below the oscillating plate.  
To stop the oscillation – tighten the regulation screw
5. Fan head can be tilted up and down.  
To tilt the head, simply move the motor housing up or down gently until the fan is positioned as required. A series of clicks will be heard - this is normal.

## CARE AND CLEANING

This appliance requires little maintenance.

After 2,000 hours of operation – the lubrication grease in the gearbox should be replaced.

We recommend dust is cleaned from the fan blade and protective grills every few months, to keep it operating optimally.

After use and before cleaning, ensure the fan is OFF and the blades have come to a complete stop.

Disassemble the front & rear grill & fan. Wipe parts with a damp cloth.

Do not use abrasive cleaners, harsh detergents, chemical cleaners or solvents as they may damage the surface finish of the plastic components.

Refit the parts following the assembly instructions

Wipe the outside of oscillating fan body with a damp cloth and dry with another cloth or paper towel.

## SERVICE & CUSTOMER CARE

There are no user serviceable parts inside this appliance.

If the power cord or plug are damaged it must, for safety reasons, be replaced by Binatone or an authorised Binatone repairer.

If you need help with:

- using your product
- servicing or repairs (in or out of guarantee)
- spare parts (fan blade, grill covers, locking nut)

Please contact Binatone Customer Service at:



[www.binatonelifestyle.com/binatone/customer-service/](http://www.binatonelifestyle.com/binatone/customer-service/)



[www.facebook.com/BinatoneAfrica](http://www.facebook.com/BinatoneAfrica)

or search @BinatoneAfrica in Facebook or Messenger to find this page easily.

Have your model number & batch code ready – it is located on the rating label on your product

# WARRANTY

**Save your proof of purchase sales receipt.**



BINATONE warrants, subject to the conditions stated below, that from the date of purchase, this product will be free from mechanical defects for a period of two (2) years.

This is a domestic product – warranty does not cover products that have been used for commercial purposes.

BINATONE at its option, will repair or replace a product found to be defective during the warranty period. Should this product become defective by reason of improper workmanship or material defect during the specified warranty period, BINATONE will repair or replace the same effecting all necessary part replacements.

Transportation charges on parts, or products in whole, submitted for repair or replacement, under this warranty, must be borne by the purchaser.

**CONDITIONS:** This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty service or replacement. Dealers, service centres, or retail stores do not have the right to alter, modify or in any way, change the terms and conditions of this warranty.

Warranty registration is not necessary to obtain warranty on BINATONE products.

**ABOUT YOUR PRODUCT WARRANTY:** Most warranty repairs are handled routinely, but sometimes requests for warranty service may not be appropriate. For example, warranty service would NOT apply if the product damage occurred because of misuse, lack of routine maintenance, shipping, handling, warehousing or improper installation. Similarly, the warranty is void if the manufacturing date or the serial number on the product has been removed or the equipment has been altered or modified. During the warranty period, the authorized service dealer, at its option, will repair or replace any part that, upon examination, is found to be defective under normal use and service.

**NORMAL WEAR & SERVICE/REPLACEABLE PARTS:** This warranty does not cover normal wear of parts or damage resulting from any of the following: Negligent use or misuse of the product; Improper voltage or current; Use contrary to the operation instructions; Deviation from instructions regarding storage and transportation; Repair or alteration by anyone other than BINATONE or an authorized service centre; service parts replaced by user. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes, tornadoes etc.

Customers connecting BINATONE appliances directly to the mains power outlet or using a non-BINATONE stabilizer, risk voiding their BINATONE warranty. We recommend using quality BINATONE stabilizers for your protection – be wise, buy the best – always buy BINATONE

**HOW TO OBTAIN WARRANTY SERVICE:** Please contact BINATONE Customer Service (see Service & Customer Care section)



**Please consider recycling this  
instruction manual responsibly**

**Binatone Lifestyle Appliances**

**• LONDON • HONG KONG • DUBAI • LAGOS • ACCRA •**